



Maxima Ultra 36

CBS Xtreme Control Board




Be ahead

Professional installation required
Welding might be required

MAXIMA ULTRA 36

Automatic electromechanical barrier with safety reopening

Professional electromechanical barrier with inverter technology and heavy-duty asynchronous three-phase motor, designed to operate across a wide range of usage conditions, like in large parking lots or motorway toll booths with frequent motion reversals.



- Self-supporting steel structure, cathaphoresis treated and powder paint coated (optional stainless steel)
- Double output shaft for installation on the right or on the left
- Opening time: **from 0.7 to 3.9 s**
- Maximum frequency: **20 000 operations/day** for arm length up to 3 m
5 000 operations/day for arm length up to 6 m
- MCBF: **7 000 000 cycles**
- Motor speed regulation
- Rod/crank mechanism ensuring the bar always moves smoothly
- Configurable obstacle detection with motion reversal while closing (encoder)
- Single spring for openings up to 6m wide
- Cap with RGB led lights (optional) providing blinking, traffic light and diagnostics functions
- Complete with installation template
- Built-in inverter
- Gearmotor in oil bath and asynchronous, three-phase motor 230 Vac
- Version with 115 Vac power supply available
- Manual opening inside the structure
- Greater accessibility thanks to the double door and to the cap
- Vandal-resistant system for interior protection.
- Control unit compatible with TCP/IP and RS485 protocol

WARNING!

Please read and follow all instructions before installing and operating this product. Follow all local and federal building and electrical codes. BFT is not responsible for faults or damage caused by improper installation, application, or failure to comply with building codes.

TECHNICAL-ENVIRONMENTAL MAIN FEATURES	
Barrier size	338 x 338 x h.1 030 mm; steel Fe360 (S 235 JR) *
Road passage	2.0...6.0 m
Finishing	Cataphoresis, powder paint RAL7015 standard, other colours on request
Foundation	Concrete, 500 x 500 x h.400 mm
Motor	Gearmotor in oil bath and asynchronous, three-phase motor, rod/crank
Obstacle detection	Configurable obstacle detection with motion reversal while closing (encoder)
Lock	Mechanic
Unlock	Manual inside the structure
Opening time	Adjustable from 0.7 to 3.9 s
Operating ambient temperature	-40°C ** +60°C
Operating humidity	up to 100%
IP grade	IP55
Net weight	69 kg
Gross weight	72 kg

* option, AISI304 or AISI316

** With integrated heater active

ELECTRICAL FEATURES	
Control unit	CSB Xtreme
Power	1-phase 230 Vac \pm 10%, 50-60 Hz 1-phase 115 Vac \pm 10%, 50-60 Hz version available
IP grade	IP55
Operating ambient temperature	-40°C ** +60°C
Operating humidity	up to 95%, non condensing
Absorbed power	370 W
Power consumption	44 W
Signalling	LED lights on the arm, cap with RGB led lights providing blinking, traffic light and diagnostics functions
Sensor inputs	<ul style="list-style-type: none"> • Photocell • Boom pushed (special breakable boom) • UPS • Emergency stop from front panel
Local/Remote control	<ul style="list-style-type: none"> • Digital inputs • Radio remote control (RX on board, TX optional) • RS485, TCP/IP (optional)

INSTALLATION EXAMPLE


1) Single-phase line	2 x 1.5 + T
2) Transmitter photocell	2 x 0.5
3) Receiver photocell	4 x 0.5
4) Key selector	2 x 0.5
5) Receiver Antenna	4 x 0.5
6) Magnetic coil	RG58

For system composition and installation refer to the regulations in force in the country where the system is being installed.



ITEM SPECIFICATION

Automatic electromechanical barrier for passage from 2.0 to 6.0 m. Dimensions 338 x 338 x h.1 030 mm. Self-supporting steel structure Fe360 (S 235 JR), cataphoresis treated and powder paint coated. IP55. Internal control unit, compatible with TCP/IP and RS485 interfaces. Gearmotor in oil bath and asynchronous, three-phase motor, rod/crank. Operating ambient temperature up to -40°C +60°C. Maximum frequency: 20 000 operations/day for arm length up to 3.0 m, 10 000 operations/day for arm length up to 4.0 m. MCBF: 7 000 000. Electric motor power 230 Vac (\pm 10%), 50-60Hz. Max power consumption 370W. Opening time: from 0.7 to 3.9 s. Configurable obstacle detection (encoder). Spring balance. Manual unlock inside the structure.

SECURING THE STRUCTURE



! Check the direction of travel indicated on the template, for precise overlapping of the rounded corners of the barrier body.



It is recommended to remove the template before securing the barrier.


Arrange in the foundation corrugated tubes for power supply and system cables (not supplied).

ELECTRICAL CONNECTIONS



BEFORE PERFORMING ANY TASK ON THE EQUIPMENT, CUT OFF THE POWER SUPPLY.


1



OPEN THE COVER AND ACCESS INSIDE THE BARRIER TO REMOVE OF THE DOORS

2

REMOVE THE COVER OF THE INTERNAL CONTROL UNIT



BEFORE PERFORMING ANY TASK ON THE EQUIPMENT, CUT OFF THE POWER SUPPLY.

BAR ALIGNMENT

1




Electrically connect the control unit (see CSB-Xtreme instructions).




Use the "Start" command to bring the bar in horizontal position.

TO ALIGN THE BAR WITH THE ROAD PAVING, OPERATE THE ADJUSTABLE BAR HOLDER

Adjustable bar holder.




2 x 10 mm




Check that the bar is in horizontal position

2




Use the "START" command to bring the bar to vertical position.

Opening microswitch cam.



Adjust the bar vertically operating the cam of the opening limit switch.



Check that the bar is in vertical position.



BALANCING THE ARM

1





Electrically connect the control unit (see CSB-Xtreme instructions).



Use the "Start" command to bring the bar in horizontal position.


TO ALIGN THE BAR WITH THE ROAD PAVING, OPERATE THE ADJUSTABLE BAR HOLDER

Adjustable bar holder.





Check that the bar is in horizontal position

2




Opening microswitch cam.



Use the "START" command to bring the bar to vertical position.




Adjust the bar vertically operating the cam of the opening limit switch.



Check that the bar is in vertical position.





SPRINGS CALIBRATION (APPROXIMATE DATA)



BTM-SKIRT
 Ra = L-530 senza / without BRACKET SKIRT
 Ra = L-400 con / with BRACKET SKIRT

FULL-SKIRT
 Ra = L-430 con / with BRACKET SKIRT
 obbligatorio / required



Do not weigh the arm down by applying other accessories

The values in the table are the same for the version with lights

MAXIMA ULTRA 36




SPRINGS CALIBRATION TABLE

TABLA DE CALIBRACIÓN DE MUELLES

© BFT spa reserves the rights to change the information hereby contained at any time and without prior notice. Pictures are only indicative and could differ from the received machine for some details.

		6' 6 ³ / ₄ "	7' 4 ⁹ / ₁₆ "	8' 2 ⁷ / ₁₆ "	9' 1 ¹ / ₄ "	9' 10 ¹ / ₈ "	10' 7 ¹⁵ / ₁₆ "	11' 5 ¹³ / ₁₆ "	12' 3 ⁵ / ₈ "	13' 1 ¹ / ₂ "	13' 11 ⁵ / ₁₆ "	14' 9 ³ / ₁₆ "	15' 7"	16' 4 ⁷ / ₈ "	17' 2 ¹¹ / ₁₆ "	18' 9 ¹ / ₁₆ "	18' 10 ³ / ₈ "	19' 8 ¹ / ₄ "		
BOOM PS		1 5 ¹ / ₈	1 5 ¹ / ₈	1 4 ¹⁵ / ₁₆	1 4 ³ / ₄	1 4 ⁵ / ₁₆	1 3 ¹⁵ / ₁₆	1 3 ⁹ / ₁₆	1 3 ³ / ₈	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ¹ / ₂	2 4 ⁵ / ₁₆	2 4	2 3 ⁹ / ₁₆	4 4 ¹⁵ / ₁₆	3 4 ¹ / ₂	3 4 ⁵ / ₁₆	3 4 ³ / ₄	
BOOM PS	+ HYPHEN PRO											2 4 ⁵ / ₁₆	2 3 ¹⁵ / ₁₆	2 3 ⁹ / ₁₆	3 4 ¹⁵ / ₁₆	3 4 ³ / ₄	3 4 ⁵ / ₁₆	3 4 ¹ / ₂	3 4	
BOOM PS	+ ADJ-FOOT									2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 3 ³ / ₄	2 3 ⁹ / ₁₆	3 4 ¹⁵ / ₁₆	3 4 ¹ / ₂	3 4 ⁵ / ₁₆	3 4	3 3 ³ / ₄	2 3 ³ / ₄	
BOOM PS	+ ADJ-FOOT											2 3 ⁹ / ₁₆	3 4 ¹⁵ / ₁₆	3 4 ³ / ₄	3 4 ⁵ / ₁₆	3 4 ¹ / ₈	3 3 ³ / ₄	2 3 ³ / ₄	2 3 ⁹ / ₁₆	
BOOM PS	+ EBB		1 4 ⁵ / ₁₆	4 4	1 3 ⁹ / ₁₆	4 5 ¹ / ₈	1 4 ¹⁵ / ₁₆	4 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 3 ³ / ₄	2 3 ⁹ / ₁₆	2 4 ¹⁵ / ₁₆	2 4 ¹ / ₂	2 4 ⁵ / ₁₆	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄
BOOM PS	+ EBB											2 3 ⁹ / ₁₆	3 4 ¹⁵ / ₁₆	3 4 ³ / ₄	3 4 ⁵ / ₁₆	3 4 ¹ / ₈	3 3 ³ / ₄	3 4 ³ / ₄	3 3 ⁹ / ₁₆	
BOOM PS	+ BTM SKIRT		1 4 ¹ / ₂	1 4	1 3 ⁹ / ₁₆	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ¹ / ₂	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4 ¹ / ₈	2 3 ³ / ₄	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄
BOOM PS	+ BTM SKIRT												2 4 ¹⁵ / ₁₆	2 4 ¹ / ₂	2 4 ¹ / ₈	2 5 ¹ / ₈	2 5 ¹ / ₈	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	
BOOM PS	+ BTM SKIRT + ADJ-FOOT												3 5 ¹ / ₈	3 4 ¹⁵ / ₁₆	3 4 ¹ / ₂	3 4 ¹ / ₈	3 4 ¹ / ₈	3 4 ¹ / ₈	3 4 ¹ / ₈	
BOOM PS	+ BTM SKIRT + ADJ-FOOT												3 4 ⁵ / ₁₆	3 4	3 5 ¹ / ₈	3 4 ¹⁵ / ₁₆	3 4 ³ / ₄	3 4 ¹ / ₂	3 4 ¹ / ₈	
BOOM PS	+ BTM SKIRT + EBB		4 3 ³ / ₄	1 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4	2 5 ¹ / ₈	2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈
BOOM PS	+ BTM SKIRT + EBB												2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	
BOOM PS	+ FULL SKIRT		1 4 ¹ / ₈	1 3 ⁹ / ₁₆	2 5 ¹ / ₈	2 4 ¹⁵ / ₁₆	2 4 ¹ / ₂	2 4	2 5 ¹ / ₈	2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4 ¹ / ₂	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈	2 4 ¹ / ₈
BOOM PS	+ FULL SKIRT												2 4 ⁵ / ₁₆	2 4	2 5 ¹ / ₈	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ⁵ / ₁₆	2 4	
BOOM PS	+ FULL SKIRT + EBB		2 5 ¹ / ₈	2 4 ¹⁵ / ₁₆	2 4 ³ / ₄	2 4 ¹ / ₂	2 4	2 5 ¹ / ₈	2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 4 ⁵ / ₁₆	2 4 ¹ / ₂	2 3 ⁹ / ₁₆	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄
BOOM PS	+ FULL SKIRT + EBB												2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	2 4 ³ / ₄	


Mandatory installation FORK-UNI



The preload value is indicative to reach the correct balancing angle indicated above.

XL version: mandatory the installation of the bar reinforcement HYPHEN PS (included)

Color	Barrier type	Springwire
	STD Version	Ø 10 mm
	XL Version	Ø 11 mm




L HAND MANOEUVRE




BEFORE PERFORMING ANY TASK ON THE EQUIPMENT, CUT OFF THE POWER SUPPLY.



DO IT ONLY WITH THE BAR MOUNTED AND POSITIONED VERTICALLY




1. INTRODUCTION

 The control unit has been developed to control automatic single-phase barriers with inverter-driven three-phase motor.


 = Electrical connections configured at the factory.

2. MAIN CHARACTERISTICS

- Microprocessor logic
- LEDs displaying inputs/outputs status
- Integrated radio receiver 433.92MHz, 2 channels, 2 048 codes
- TCP/IP module and RS485 module (Option)
- 3-digit display for programming and system status
- Up to 4 configurable outputs
- Radio programmer connector
- Built-in heater for cold climates (Termon)



- | | |
|---|--|
| J1: Control unit power supply | J10: Expansion connector |
| J2: Inverter power supply | J12: Radio programmer connector |
| J3: Transformer connector | DL: 3-digit LED display |
| J4: Flashing light output | START: "START" control button |
| J5: Outputs/accessories power supply | F1: Transformer primary fuse: 500 mA T (230Vac) - 1 AT (115Vac) 5x20mm |
| J6: Encoder/inputs | F2: Line fuse (control board and inverter): 4 AT (230Vac) - 8 AT (115Vac) 5x20 mm |
| J7: Inputs/antenna | F3, F4: Transformer secondaries fuses: 2 AT 5x20mm |
| J8: Boom lights connector | F, -, +: Programming push buttons |
| J9: Inverter signals | PR1, PR2: Radio receiver programming push buttons |



3. TECHNICAL SPECIFICATIONS

- Power supply:.....230Vac ±10%, 50/60Hz (115Vac on request)
- Flashing light output:.....230Vac; 40W max
- Accessory output:.....24Vac; 24W - 1A max

4. INSTALLATION SAFETY

In order to reach the level of safety required by current regulations, follow these prescriptions carefully.

- 1) Make all connections in the terminal block after carefully reading the instructions given in this manual and observing the general rules and technical standards concerning electrical systems installations.
- 2) Always fit an omnipolar circuit breaker with a contact gap of at least 3 mm.
- 3) Install a differential circuit breaker with a threshold of 30 mA.
- 4) Check the effectiveness of the protective earth and connect to it all the parts of the automation fitted with a terminal or grounding cable.
- 5) Fit at least one external warning device, such as a traffic light or flashing light, along with a warning or danger sign.
- 6) Fit all the safety devices required by the type of installation, taking into consideration the risks it on cause.
- 7) Separate keep power lines (1.5 mm² min. section) from the low-voltage signal lines (0.5 mm² min. section).



5. PRELIMINARY OPERATIONS

Barriers with standard booms are automatically selected. For special booms (barrier 35 only), before operating the automation, make sure to have correctly selected the barrier/boom type as follows:

- Press and hold down buttons F and + for 5 seconds.
- Select the barrier/boom type using buttons +/-.
- Press together F and + to confirm.
- Select the actual barrier/boom being used.

Are presented the following choices, depending on the type of INVERTER:

MAXIMA ULTRA 35 / MAXIMA ULTRA 68

Б-В	MAXIMA ULTRA 68 (auto select)	9D	Boom ATM 90° (ULTRA 35 only)
Э-5	MAXIMA ULTRA 35 (auto select)	18D	Boom ATM 180° (ULTRA 35 only)
С-в	Boom Carbon (ULTRA 35 only)		


MAXIMA ULTRA 36

Э-В	MAXIMA ULTRA 36 (auto select)	ЭВР	Boom ARTICULATED
ЭВС	Boom Carbon	ЭВd	Xtreme DD4 (fail safe)

The Company is not liable for injury to people or animals or damage of things in case of wrong selection of the barrier. Selecting wrong barrier/boom void warranty.

6. INPUT AND OUTPUT FUNCTIONALITY AND CONNECTIONS


6.1 J1 CONTROL UNIT POWER SUPPLY



230Vac 50/60Hz power supply.
Connect LINE and NEUTRAL wires as shown on the board. Use cable type H07RN-F 2x1.5+E min.
Connect the yellow/green EARTH wire of the power supply mains to the earth terminal of the appliance.



6.2 J4 FLASHING LIGHT OUTPUT




Output 230Vac, 40W max.


6.3 J5 OUTPUTS/ACCESSORIES POWER SUPPLY




OUT24
Output 24Vac, 1A max



OUT2
Programmable dry relay output, max. 500mA 24 Vac/dc (parameter o2 - level 2)




OUT3
Programmable dry relay output, max. 500mA 24 Vac/dc (parameter o3 - level 2)



OUT4


Programmable dry relay output, max. 500mA 24 Vac/dc (parameter $\sigma 4$ - level 2)



OUT5/CH2 RX


Programmable dry relay output, max. 500mA 24 Vac/dc or N.O. output of the 2nd radio receiver channel (parameter $\sigma 5$ - level 2)

6.4 J6 ENCODER/INPUTS



ENCODER

Supplied already wired. Encoder can trigger in the closing movement only, when the boom hits an obstacle. Select the desired behaviour by programming the parameter $E\bar{C}$ - level 1. +V terminal can be used for powering additional sensors (16Vdc not stabilized-100mA max)



FRAC

N.C. additional safety input for swinging boom sensor. When activated (open) it stops the automation immediately. Subsequent START always cause reopening.



UPS

UPS status input. Use with UPS having dedicate output (closed contact when UPS active) The control unit has also an internal detector that works with simpler square-wave UPS. With these simpler UPS there is no need to use this input.




START

N.O. input for controlling the automation according to four-step logic: open-stop-close-open.



PDM INPUT

Programmable input, parameter Pd -level 3. This signal can be duplicated on an programmable output (see OUT2, 3, 4, 5).



OPEN

N.O. input - opens the boom. This input has priority over CLOSE command and can be kept always activated until necessary. Connect loop detectors, clocks, daily or weekly timers here, where and if necessary.

6.5 J7 INPUTS/ANTENNA



CLOSE

N.O. input for closing. It allows the automation to be closed only if the safety devices have not triggered. Operating mode programmable with parameter $\bar{C}L$ -level -1.




FTC

N.C. safety input (photocell). Enter the desired behaviour by programming the $F\bar{E}$ -level-1 parameter. It only triggers in the closing phase; it never triggers in opening.



STOP

N.C. safety input. When activated it instantly stops the automation and a subsequent start always cause reopening. During pause time a stop command disables automatic reclosing, leaving the bar open waiting for commands. NOTE: The hatch microswitch is already connected to this input.



8k2

Multi-purpose analog input. For TERMON heater see paragraph 9.3.



FCA

Limit switch N.C. input in opening. When activated the opening travel finishes.



FCC


Limit switch N.C. input in closing. When activated the closing travel finishes.




ANTENNA

Antenna connection for the integrated receiver


6.6 **J8** BOOM LIGHTS CONNECTOR



6.7 **J10** EXPANSION CONNECTOR




6.8 **J12** RADIO PROGRAMMER CONNECTOR



7. INVERTER CONNECTIONS

7.1 **M** MOTOR




7.2 **J2** INVERTER POWER SUPPLY (all types)



7.4 **J9** TYPE 2 INVERTER SIGNALS

TYPE 2 INVERTER (J2)




CONTROL UNIT (J9)

- B:** Gray
- A:** Pink
- GND/COM:** Green
- FWD:** Yellow
- REV:** White

(J6)

- +V ENC:** Brown



9.1 BASIC FUNCTIONS

To access programming, press button **F** for 2 seconds.

Programming is divided into 4 levels.


To go to the next level keep key **F** pressed and press the + key (Sequence 1-2-3-1.....).

After selecting the desired level, press push button **F** to display the functions available in consecutive order. Each **F** pression corresponds to a function (L0 - CL - Ft - EC.....)

With the function set, use the (+) or (-) key to change the values of the parameters (00-0 1-02-03... / ...03-02-0 1-00).

Changes made to the parameters are active immediately but will be saved when exiting the menu, selecting the 5t function with key **F**.


PLEASE NOTE: All changes will be lost in case of black-out during when programming phases .




Example:
 Selecting Output2 on closed boom:

(A) □ x 2" F [Hand icon]	(B) □ + □ F + [Hand icon]	(C) □ x 5 F [Hand icon]	(D) □ x 4 + [Hand icon]	(E) □ x 3 F [Hand icon]
2nd level	02	04=boom closed	5t	

The following table gives the 1st level functions and the single settable parameters.

 = DEFAULT value set in factory.



 = parameter value set during installation: must be indicated if DEFAULT value is modified.

Par	Function	Settable data		
L0	Selects the functioning logic. (see notes after the table)	00: Hold-to-run	01	
		01: Semi automatic		
		02: Automatic		
CL	Close input configuration (see notes after the table)	00: Standard close input	00	
		01: Close-when-released input		
		02: The close command acts as a release closing and safety function.		
Ft	Photocells	00: When closing it stops and waits for disengaged photocell commands	02	
		01: When closing it stops; reclosing after 1" when the photocell is disengaged		
		02: When closing it reopens; reclosing after 1" when the photocell is disengaged		
		03: When closing it reopens; reclosing after 5" when the photocell is disengaged		
		04: When closing it reopens; reclosing when the photocell is disengaged and resets the eventual pause time		
		05: When closing it reopens and waits for disengaged photocell commands		
EC	Encoder	00: Excluded	03	
		01: When closing it stops and waits for commands		
		02: When closing it reopens and waits for commands		
		03: When closing it reopens, reclosing after 5 seconds		
ES	Encoder sensitivity	01 - 09 (minor - major obstacle sensitivity)	01	
PF	Warning flash	00: Excluded	00	
		01: Before each movement on a configured output (see parameters 02,03,04,05 in the 2nd level table)		
		02: Before each movement on a configured output and on the boom lights		
Lb	Arm and head lights	00: When moving flashing red light, when the boom is closed and open off red light.	03	
		01: When moving flashing red light, when the boom is closed and off when the boom is open on red light.		
		02: When moving and with the boom closed flashing red light, when stopped and on red light when the boom is open on red light.		
		03: When moving flashing red light, when the boom is closed and on green light when the boom is open off red light.		
		04: When moving flashing red light, when the boom is closed and on green light when the boom is open on red light.		
EP	Pause time (expressed in seconds)	00-99	10	
Pb	Arm lights brightness	00: 40%	03	
		01: 60%		
		02: 80%		
		03: 100%		

00	Cap light when opened boom	00: Off	01	
		01: Red		
		02: Green		
		03: Blue		
		04: Pink		
		05: Dark pink		
		06: Orchid		
		07: Purple		
		08: Magenta		
		09: Blue/Purple		
		10: Cyan		
11: Light blue				
02	Cap light when closed boom	12: Turquoise	02	
		13: Sky Blue		
		14: Aquamarine		
		15: Light green		
		16: Olive green		
		17: Yellow/Green		
		18: Yellow		
		19: Orange		
		20: Salmon		
		21: Warm white		
		22: White		
23: Cool white				
dF	Resetting default parameters. (see notes after the table)	00: No resetting	00	
		01: Resetting the default valves parameters and boom type		
		02: Parameters Set up to default values, except for "COM" parameter : communication protocol		
5t	Exiting the menu/saving	Pressing the "F" key, the programming menu is quit and the changes saved.		

NOTES:

- **00: Functioning logic**
 - Hold-to-run: The automation works when the commands are held down. The start command opens once and closes once.
 - Semi automatic: The automation works with jog commands, without automatic reclosing. Hence, when fully open, to control closing you need to act on the start or close command respectively.
 - Automatic: The automation works in jogs. When the opening manoeuvre is completed in the standard cycle, automatic reclosing is activated after the pause time set (parameter EP; with FE=04 the pause time is reset when the photocell is disengaged, in order to close immediately after the vehicle passage).
- **02: Close configuration**
 - 01: Close-when-released input
This mode has been developed in order to automatically close the boom only when the vehicle has completely passed-out the photocell or magnetic detector (the most suitable accessories for this purpose).
Connect the N.O. contact of the detector or photocell to the Close contact terminals.
If the vehicle is on the detector or in front of the photocell it does not cause immediate closing but rather you have to wait for the signal to be released.
 - 02: The close command acts as a release closing and safety function.
When closing, the close command engaging stops the automation. When disengaged the barrier resumes closing.
- **dF: Default**
 - To restore the parameters to them factory default values, set the "dF" to 1 or 2, then quit from menu. With 2 the communication "Com" setting is kept.

Par	Function	Settable data		
tL	Maximum operating time (sec.)	03-30	15	
sr	Request for maintenance (see notes after the table)	00: disabled	00	
		01: active on the configured outputs		
		02: active on the configured outputs and the bar lights flash twice		
nt	Programming maintenance cycles in thousands (see notes after the table)	00-99	00	
nL	Programming maintenance cycles in millions (see notes after the table)	0.0-9.9	0.0	
$o2$ $o3$ $o4$ $o5$	Output 2, Output 3, Output 4, Output 5	00: request for maintenance	$o2=05 - o3=04 - o4=02 - o5=14$ $o2=20 - o3=04 - o4=02 - o5=20$	
		01: photocell triggering		
		02: encoder triggering		
		03: PDM contact actuated		
		04: boom closed		
		05: boom opened		
		06: stop contact actuated		
		07: warning flash		
		08: Boom locking device		
		09: opened triggering		
		10: closed contact activated		
		11: start triggering		
		12: FRAC triggering		
		13: UPS triggering		
14: second radio channel triggering (only OUT 5)				
te	Termon (see notes after the table)	00: Disabled	00	
		01: Enabled and always active		
		02: Enabled when needed by means of NTC sensor connected between 8k2 and COM input terminal		
UP	UPS (see notes after the table)	00: disabled	00	
		01: enabled, opens automatically during mains failure		
		02: enabled, closes automatically during mains failure ⚠ ATTENTION: THIS SELECTION MAY BE DANGEROUS		
st	Exiting the menu/saving	Pressing the "F" key, the programming menu is quit and the changes saved.		

NOTES:

• sr : Request for maintenance

00: the request for maintenance is not active.

01: at the end of the countdown, by means of counters nt and nL , one of the programmed outputs is activated (see parameter $o2, o3, o4, o5$)

02: at the end of the countdown, by means of counters nt and nL , one of the programmed outputs is activated (see parameter $o2, o3, o4, o5$) and the bar lights flash twice.

• nt and nL : Programming maintenance cycles in thousands and millions

By the combination of the two parameters the countdown can be set after which a request for maintenance is signalled.

Thousands can be set with the nt parameter, millions with the nL parameter.

Example: to set 275 000 maintenance manoeuvres set nL on 0.2 and nt on 75.

The value displayed in the parameters updates along with the manoeuvres.

• te : TERMON (integrated motor heater system).

01: system is always ON. Must be used only with maximum ambient temperature less than +10°C

⚠ WARNING: ambient temperatures >10°C may cause overheating and damages to the motor, not covered by warranty

02: system is activated depending on motor temperature, measured by a temperature sensor (option). In case of sensor failure, system reverts to setup 01

• UP: UPS

UPS TYPE	
Square-wave	Internal detector, UPS input not connected
UPS with sinusoidal or quasi-sinusoidal wave form, with dedicated output for signaling the absence of power net	Connect mains failure output to UPS input
Pure-sinusoidal wave UPS with dedicated output for signaling the absence of power net	Use 230Vac relays, coil connected to mains supply, close contacts to UPS input

• Boom locking device configuration:

To use the boom locking device, connect the enabling contact to OUT2 or OUT3 or OUT4 or OUT5 and set the corresponding parameter $\alpha 2, \alpha 3, \alpha 4$ or $\alpha 5$ to $\overline{00}$. Set advance electric lock disengagement ($r 5$ -3rd level)

9.4 3RD LEVEL PROGRAMMING

The following table gives the 3rd level functions and the single parameters.



= DEFAULT value set in factory.



= parameter value set during installation: must be indicated if DEFAULT value is modified.

Par	Function	Settable data		
$P 5$	Advanced setup (see notes after the table)	$\overline{00}$: no advanced setup	$\overline{00}$	
		$\overline{01}$: N/A		
		$\overline{02}$: controlled entry and automatic exit		
$P d$	PDM dynamic input polarity	$\overline{00}$: input N.O.	$\overline{00}$	
		$\overline{01}$: input N.C.		
$P 2$ $P 3$ $P 4$ $P 5$	Output 2 polarity Output 3 polarity Output 4 polarity Output 5 polarity (see notes after the table)	$\overline{00}$: N.O.	$\overline{00}$	
		$\overline{01}$: N.C.		
$r 5$	Advance electric lock disengagement (see notes after the table)	$\overline{00}$: 0,5s - $\overline{01}$: 1s - $\overline{02}$: 1,5s - $\overline{03}$: 2s - $\overline{04}$: 2,5s - $\overline{05}$: 3s	$\overline{00}$	
$\overline{05}$	Opening speed (%)	$50 - 99$ (ATM 90°, ATM 180°)	66	
		$50 - 99$ (MAXIMA ULTRA 35, Carbon)	50	
		$50 - 99$ (MAXIMA ULTRA 68)	55	
$\overline{C 5}$	Closing speed (%)	$40 - 99$ (MAXIMA ULTRA 68, ATM 90°, ATM 180°)	53	
		$40 - 99$ (MAXIMA ULTRA 35, Carbon)	40	
$F P$	Speed selection input (see notes after the table)	$\overline{00}$: Disabled	$\overline{00}$	
		$\overline{01}$: Enabled		
		$\overline{02}$: MAXIMA ULTRA 36 cap lights for parking function		
$F r$	Swinging boom sensor input (see notes after the table)	$\overline{00}$: swinging boom not mounted or disabled	$\overline{00}$	
		$\overline{01}$: swinging boom sensor mounted and activated N.C.		
$S t$	Exiting the menu/saving	Pressing the "F" key, the programming menu is quit and the changes saved.		

NOTES:

• $P 2, P 3, P 4, P 5$: Output polarity

Output polarity: The outputs can be configured as N.O. or N.C. but, in the event of a blackout the contacts open anyway.

• $F P$: Velocity selection input

By enabling this parameter bar speed can be adjusted via the PDM input ($\overline{01}$), or it is possible manages the color of the cap for report the free seats in the parking systems ($\overline{02}$).

$\overline{01}$ If the PDM is activated and parameter $F P$ enabled the barrier moves at a speed equal to 60% of maximum speed, both when opening and closing.

$\overline{02}$ The PDM manages the RED/GREEN color of the cap and report the free seats in the parking systems (see paragraph 10)

• $r 5$: Advance electric lock disengagement

This parameter adjusts the delay between electro-lock deactivation and engine start, to allow the resetting of the residual magnetism of the electro lock.

• $P 5$: Advanced setup

This parameter enables the use of special configurations for specific necessities.

$\overline{01}$ N/A.



$\overline{02}$ Controlled entry and automatic exit (see paragraph 13).

- Fr: Swinging boom sensor input N.C.
- 00 swingin boom sensor not mounted or disabled
- 01 automation stops immediately in case of swinging boom opened

9.5 4TH LEVEL PROGRAMMING

The following table gives the 4th level functions and the single parameters.

 = DEFAULT value set in factory.  = parameter value set during installation: must be indicated if DEFAULT value is modified.

Par	Function	Settable data		
<u>Con</u>	Communication protocol (see notes after the table)	00: disabled	00	
		01: U-LINK		
		02: Modbus/RTU		
<u>Uno</u>	Setting U-LINK mode	00: Slave	00	
		01: Master		
		02: Slave for opposing barriers		
		03: Master for opposing barriers		
<u>Uld</u>	Setting U-LINK adress	000 - 119	000	
<u>Mid</u>	Setting Modbus/RTU ID	000: For Master	001	
		001 - 247: For Slave		
<u>NSP</u>	Setting MODBUS RTU speed	00: 19 200 baud	01	
		01: 38 400 baud		
<u>tot</u>	Operation counter	Operation counter. Read-only parameter, expressed in hundreds of operations.		
<u>Err</u>	Error History (see notes after the table)	Exx: error list and occurrence alternatively shown (see chapter 14 "ERROR HANDLING")	000	
		000: no history clear		
		001: history is clear		

NOTES:

• Con:
Setting communication protocol. **Set value always same to Master and Slave.**

• Err:
The error list and the occurrence are alternatively shown .
Such as:

E21 $\xleftrightarrow{\text{alternating}}$ 002

RADIO RECEIVER

11.1 RECEIVER TECHNICAL SPECIFICATIONS


- Max. n° of radio transmitters that can be memorized:	2 048
- Frequency:	433.92MHz
- Code by means of:	Rolling-code algorithm
- N° of combinations:	4 billions

11.2 RADIO CHANNEL FUNCTIONALITY

Channel 1:	Start command
Channel 2:	Closes the relay contact on the terminal block J5 "CH2 RX"

10.3 ANTENNA INSTALLATION

Use an antenna tuned to 433MHz. Connect the tuned antenna to the antenna terminals using RG58 coaxial cable.



11.4 MANUAL PROGRAMMING

In case of standard installations where no advanced functions are required, it is possible to proceed to manual storage of the transmitters, making reference to programming table A and to the example for basic programming.

- 1) If you wish the transmitter activate output 1, press pushbutton PR1, otherwise if you wish the transmitter activate output 2, press pushbutton PR2.
- 2) When LED DL1 starts blinking, press hidden key on the transmitter, LED DL1 will remain continuously on.
- 3) Press the key of the transmitter to be memorized, LED DL1 will flash quickly to indicate that it has been memorized successfully. Flashing as normal will then be resumed.
- 4) To memorize another transmitter, repeat steps 2) and 3).
- 5) To exit memorizing mode, wait for the LED to go off completely or press the key of a remote control that has just been memorized.

IMPORTANT NOTE: ATTACH THE ADHESIVE KEY LABEL TO THE FIRST MEMORISED TRANSMITTER (MASTER).

In the case of manual programming, the first transmitter assigns the key code to the receiver; this code is necessary in order to carry out subsequent cloning of the radio transmitters.



Hidden key

11.5 SELF-LEARNING MODE PROGRAMMING


This mode is used to copy the keys of a transmitter already stored in the receiver memory, without accessing the receiver.

The first transmitter is to be memorised in manual mode (see paragraph 10.4).

- a) Press hidden key on the transmitter already memorised.
- b) Press key T on the transmitter already memorised, which is also to be attributed to the new transmitter.
- c) Within 10 s., press hidden key on the new transmitter to be memorised.
- d) Press key T to be attributed to the new transmitter.
- e) To memorise another transmitter, repeat the procedure from step (c) within a maximum time of 10 seconds, otherwise the receiver exits the programming mode.
- f) To copy another key, repeat from step (a), having waited for the receiver to exit the programming mode (or after disconnecting the receiver from the power supply).



Hidden key



12. WARNINGS


It is recommended to make an installation which has all the accessories necessary to ensure operation according to current provisions, always using genuine devices.

This equipment must be installed and used in strict compliance with the manufacturer's instructions. The manufacturer cannot be held responsible for any damage deriving from improper or unreasonable use.


The constructor disclaims all liability for any inaccuracies contained in this booklet and reserves the right to make changes at any time without any prior notice whatsoever.

TABLE A


When pressing the key PR1 (for channel 1) or PR2 (for channel 2) for the first time, the receiver sets to the programming mode. Every time the key PR is pressed after that, the receiver switches to the configuration for the subsequent function, that is indicated by the number of flashings (see table).
At this stage, after selecting the channel (PR1 or PR2) and the desired function, the key T (T1-T2-T3 or T4) of the transmitter will be stored in the memory of the receiver as indicated in the table for programming.



Standard Programming




Advanced Programming



CONTROLLED ENTRY AND AUTOMATIC EXIT

This solution is recommended when you want to enter a reserved area in both directions. To enter, transit is allowed by means of a recognition command while exiting is automatic.


ENTRY



The recognition system enables barrier opening.
If the coil **S1** is not occupied within the pause time, the barrier closes again.

When coil **S1** is cleared, the barrier starts closing instantaneously.

EXIT




The vehicle approaches the reserved area. When the coil **S2** is occupied, barrier opening is enabled.
If the coil **S1** is not occupied within the pause time, the barrier closes again.

When coil **S1** is left, the barrier starts closing instantaneously.

Loop **S1** also perform as safety function not permitting the barrier closure as long as barrier is occupied.

DIMENSIONS



- Connect the coil **S1** to the **CLOSE** input.
- Connect the **N.O.** contact of the **S2** loop receiver to input **START**.
- The dimensional values of the loops are only approximate.
- * We suggest installing the "RME 2" metal mass detector.
- Only use recognition systems other than remote control units (badge readers, video camera systems with license plate recognition etc.) with contact, which must be connected to the **OPEN** input.

PARAMETER	DATA	DESCRIPTION
<i>L_o</i>	02	Automatic
<i>C_L</i>	02	The close control closes when pressed and released, and also functions as a safety system.
<i>A5</i>	02	Advanced Setup: controlled entry and automatic exit

14. TROUBLESHOOTING GUIDE

- In case of a malfunction, check if the correct barrier was selected (paragraph 5)
- Dual flashing of the cover lights. Indicates that scheduled maintenance is required. Check the parameters 5r-2ND level, nL-2ND level, nL-2ND level.
- Leakage current to ground problem: the Inverter type 1 have a built-in high-attenuation noise filter and are grounded via a capacitor. Switch a pulled to reduce the leakage current to ground. The reduced load get the inverter not compliance with the EMC standard operate on switch with power off.

15. ERROR HANDLING

In memory up to 10 different errors, with its own occurrence limited to 10, are stored for each event.

In case of blocking error, the restart of the board is possible by keep pressed both the keys "+" and "-" for 5 seconds or by switch off and on the power supply. Restarting by keys, a memory check is performed with an automatic recovery of parameters out of range to default factory values.

At level 4, by parameter "Err", the list of events and error stored in memory may be shown. It's shown alternatively the error code E_{xx} and the occurrence; use "+" e "-" for scroll the list. At the end is shown the exit code: quitting (by pressing "F") with 000 the error list is preserved, quitting with 00 1 the history is clear.

Particular events not dangerous for properly execution are stored in memory, without block the automation. Following the list of error and events with the indication of blocking or not property.

FAULT AND EVENTS TABLE:

Par	Description	LOCKING
E 10	Internal error on memory access.	NO
E 14	Out of range memory address.	YES
E 15	CRC on incorrect memory	YES
E20	Fuse F3 or F4 blow.	YES
E21	During the operation a STOP occurred, changing the normal automation.(*)	NO
E22	During the operation a FRAC occurred, changing the normal automation.(*)	NO
E23	Obstacle detected during operation.	NO
E24	Time-out elapsed in opening operation .	NO
E25	Time-out elapsed in closing operation.	NO
E27	Interruption on Ulink communication.	NO
E28	Programmed maintenance cycles reached.	NO
E29	Loss of communication with INVERTER	NO
E30	No. of ENCODER pulses out of range	NO
E31	Limit switch not working	NO
E40	Interruption on inverter communication, check the connection cable.	NO
E41	Inverter parameters password protected, must insert the password on the inverter.	NO
E94	Baud rate on incorrect communication	YES
E95	Modbus parity parameter error. Internal error.	YES

(*) Events occurrence that change the normally automation (such as stopping, change of the direction operation, not operation starting) are stored.

For example if a STOP signal turn on and off during a static status, the event is not saved; but if its presence prevents a command actuation, or when stops a started operation, it is stored.

Top cover with or without lights for *Maxima Ultra 36*


TOP COVER PREPARATION

DANGER! Always disconnect the power supply before attempting any work on the system.

Top cover with light only





1 For electrical connections, please consult the installation manual for **ALLU2 Xtreme - ALLU2 MAXIMA ULTRA.**

For grounding connections, please consult the installation manual for **CSB Xtreme.**









TOP COVER WITHOUT LIGHT INSTALLATION

CROWN MAXIMA U36



TOP COVER WITH LIGHT INSTALLATION

CROWN RGB N&D 36 XT • CROWN RGB MAXIMA U36



CROWN MAXIMA U36


ALLU2 MAXIMA ULTRA / ALLU MAXIMA ULTRA

- Power supply lights R/G


 **DANGER!** Always disconnect the power supply before attempting any work on the system.

ALLU2 MAXIMA ULTRA

RED AND GREEN STRIP LED LIGHT PS - KIT LIGHT PS




LED LIGHT FOR CROW RGB MAXIMA U36




A BAR PREPARATION

1




!
LIGHT PS30-IP67 / LIGHT PS60-IP67
- it must be centered perfectly with the track
- it must not leave the track


2



3





4




REFER TO THE USE AND INSTALLATION MANUAL OF
THE BOOM MOUNTING FOR MAXIMA ULTRA 36

B BAR INSTALLATION



C LIGHT CABLE POSITIONING



! FOR THE ELECTRICAL CONNECTIONS OF THE LED LIGHTS, SEE ALLU2 Xtreme / ALLU2 MAXIMA ULTRA POWER SUPPLY INSTRUCTION

GENERAL INFO

The **OMEGA FRA PS XTREME 36/OMEGA FRA PS MAXIMA U36** kit allows push-out fastener the BAR PS/BOOM PS to the NIGHT&DAY 36 XTREME / MAXIMA ULTRA 36 barriers.
The maximum admissible passage is 5 meters




Disconnect the power supply before carrying out any interventions on the system.




The symbol indicates operations which, if performed incorrectly, may pose CRUSHING risks.



KIT COMPOSITION



EQUIPMENT




A LAYOUT




B PUSH-OUT BAR HOLDER PREASSEMBLY

1 RIGHT



2 LEFT




(1) OMEGA FRA PS XTREME 36 / OMEGA FRA PS MAXIMA U36 SENSOR CABLE


C

PUSH-OUT BAR HOLDER INSTALLATION


1



2



3




(1) OMEGA FRA PS XTREME 36 / OMEGA FRA PS MAXIMA U36 SENSOR CABLE

D SENSOR CABLE CONNECTION


! ALWAYS DISCONNECT THE ELECTRICITY WITH A CUT-OFF SWITCH BEFORE ATTEMPTING ANY WORK ON THE SYSTEM.

1




RIGHT barrier

(1) SENSOR CABLE




2




LEFT barrier

(1) SENSOR CABLE



3

CONNECTION TO CSB XTREME CONTROL UNIT WITH PNP SENSOR



MAXIMA ULTRA 36

OMEGA FRA PS XTREME 36 / OMEGA FRA PS MAXIMA U36 SENSOR CABLE

E BOOM MOUNTING AND LIGHT PS INSTALLATION (OPTIONAL)


 ALWAYS DISCONNECT THE ELECTRICITY WITH A CUT-OFF SWITCH BEFORE ATTEMPTING ANY WORK ON THE SYSTEM.

1



(1) SENSOR CABLE

(2) OPTIONAL
LIGHT PS R/G LED LIGHT BARS





(*) SEE THE PRODUCT INSTALLATION AND USE MANUAL.

2

(1) SENSOR CABLE

(2) OPTIONAL
LIGHT PS R/G LED LIGHT BARS



 FOR THE ELECTRICAL CONNECTIONS OF THE LED LIGHTS, SEE ALLU2 Xtreme / ALLU2 MAXIMA ULTRA POWER SUPPLY INSTRUCTION.

3

